

DIP SWITCH SETTING FOR TIME ZONE DISPLAYS:

APPENDIX E

SLAVE DISPLAYS:

ADDRESS DIP

Switches 1 & 2 are used to control baud rate

1 OFF & 2 OFF = 1200 baud

1 ON & 2 OFF = 2400 baud

1 OFF & 2 ON = 4800 baud

1 ON & 2 ON = 9600 baud

Switches 5, 6, 7, & 8 ARE NOT USED

FUNCTION DIP

Switches 1, 2, 3, & 4 are used for Time Zone Adjustments (add all values)

PRODUCT MANUAL

- 1 ON adds or subtracts 1 hour
- 2 ON adds or subtracts 2 hours
- 3 ON adds or subtracts 4 hours
- 4 ON adds or subtracts 8 hours

Switch 5 (30 Minute Time Zone)

ON = 30 MINUTES WILL BE ADDED OR SUBTRACTED BASED ON SWITCH 8
8
OFF = THER WILL BE NO 30 MIN ADDITION OR SUBTRACTION.

Switch 6 IS NOT USED

Switch 7 is 12/24- hour select

- 7 ON = 12-hour mode
- 7 OFF = 24-hour mode

Switch 8 is used to select ADD or SUBTRACT Time Zone Adjustment

- 8 ON = SUBTRACT switches 1 through 4
- 8 OFF = ADD switches 1 through 4

WARNING – SHOCK HAZARD!

Always completely disconnect power from the display before opening the unit. Do not reapply power to the display until the unit has been securely closed.

