


CPU Board (ETP_M??)

or



CPU Board (ETP_M??)

Warning: Must place a RS232 driver IC into the socket of U13,for example MAX232,etc.

Title			
How of connect MODEM with Moving sign (Cpu board is ETP_M??)			
Size	ETP_M?? modem_2.sch		Revision
B			V2.00
Date:	5-Nov-2003	Sheet of	
File:	D:\FILES\DZTP\MTP_M01\Ex000 Modem	Drawn By:	Wen qingping