



Title		
How to connect PC with Moving sign(Cpu board is ETP_M??) by RS232C.		
Size	Number	Revision
B	RS232_3_sch	V3.00
Date:	5-Nov-2003	Sheet of
File:	D:\FILES\ENG_TP\说明书 Backup of RS232C\DDR	Wen qingping